


GREENWORKS

COMMERCIAL

Zero Turn Mower
2508902 (Model No.GZM60R)



Parts Manual

TOLL-FREE HELPLINE: 1-855-470-4267

www.GreenworksCommercial.com


 Read all safety rules and instructions carefully before operating this tool.

CONTENTS

FRAME ASSEMBLY.....	3
RIGHT CONTROL ARM.....	6
RIGHT RETURN ASSEMBLY.....	9
LEFT CONTROL ARM.....	11
LEFT RETURN ASSEMBLY.....	14
DECKLIFT ASSEMBLY.....	16
BATTERY COVER ASSEMBLY.....	18
CONTROLLER BOX ASSEMBLY.....	20
ROLL OVER PROTECTIVE STRUCTURE.....	22
MOWER DECK ASSEMBLY.....	24
SEAT ASSEMBLY.....	27
ELECTRICAL COMPONENTS.....	29

NOTE: ILLUSTRATIONS MAY OR MAY NOT REPRESENT THE ACTUAL ASSEMBLIES AND IT IS NOT RECOMMENDED TO USE THIS MANUAL AS A GUIDE TO ASSEMBLE OR DISASSEMBLE THE MOWER.


FRAME ASSEMBLY



ITEM NO.	PART NO.	DESCRIPTION	QTY
1-1	R0200486-00	Frame weldment	1
1-2	R0200464-00	Floor plate	1
1-3	R0200376-00	Knob bolt	5
1-4	R0200377-00	Rubber pad	4
1-5	R0200467-00	Pointer	1
1-6	R0200509-00	Bolt M10×25	6
1-7	R0200514-00	Lock nut M10	2
1-8	R0200488-00	Right console assembly	1
1-9	R0200481-00	Control box assembly	1
1-10	R0200583-00	Right fender	1
1-11	R0200449-00	Rear baffle	1
1-12	R0200445-00	Lower back cover	1
1-13	R0200520-00	Lock nut M8	8
1-14	R0200548-00	Washer	4
1-15	R0200495-00	Bolt M10×40	2
1-16	R0200473-00	Manual release plate	2
1-17	R0200539-00	Nut M10	2
1-18	R0200532-00	Bolt assembly	6
1-19	R0200526-00	Bolt M8×20	4
1-20	R0200615-00	Upper bracket weldment	2
1-21	R0200527-00	Bolt m8×25	4
1-22	R0200582-00	Left fender	1
1-23	R0200534-00	Bolt assembly	12
1-24	R0200549-00	Nut M8	6
1-25	R0200669-00	Motor drive assembly	2
1-26	R0200765-00	Bolt M10×50	8
1-27	R0200499-00	Spring washer	8
1-28	R0200502-00	Washer	10
1-29	R0200431-00	Spacer, Motor mount	4
1-30	R0200485-00	Left console assembly	1

ITEM NO.	PART NO.	DESCRIPTION	QTY
1-31	R0200551-00	Bolt M5×16	2
1-32	R0200684-00	Zerk Fitting M6	2
1-33	R0200668-00	Light LED	1
1-34	R0200545-00	Washer	2
1-35	R0200538-00	Spring washer	2
1-36	R0200511-00	Nut M5	2
1-37	R0200685-00	Caster weldment	2
1-38	R0200375-00	Oil seal	2
1-39	R0200374-00	Bearing	4
1-40	R0200373-00	Spring washer	6
1-41	R0200372-00	Lock nut M20	2
1-42	R0200686-00	Dust cap	2
1-43	R0200670-00	Front wheel assembly	2
1-44	R0200371-00	Bolt M12×236	1
1-45	R0200370-00	Front wheel	1
1-46	R0200369-00	Lock nut M12	2
1-47	R0200708-00	Rear wheel 24×12-12	2
1-48	R0200368-00	Nut 1/2-20unf	8
1-49	R0200378-00	Spring washer	4
1-50	R0200509-00	Bolt M10×25	4
1-51	R0200677-00	Lever assy	2

RIGHT CONTROL ARM




ITEM NO.	PART NO.	DESCRIPTION	QTY
2-1	R0200721-00	Blade high and low speed switch	1
2-2	R0200717-00	PTO switch	1
2-3	R0200455-00	Right control cover	1
2-4	R0200719-00	High and low drive switch	1
2-5	R0200718-00	Linear actuator	1
2-6	R0200482-00	Right return assy	1
2-7	R0200564-00	Screw M6×6	1
2-8	R0200596-00	Shaft weldment	1
2-9	R0200518-00	Lock nut M6	2
2-10	R0200527-00	Bolt m8×25	7
2-11	R0200520-00	Lock nut M8	11
2-12	R0200506-00	Bolt M10×25	3
2-13	R0200457-00	Console plate	1
2-14	R0200514-00	Lock nut M10	4
2-15	R0200535-00	Bolt M8×30	1
2-16	R0200519-00	Nut M8	1
2-17	R0200614-00	Bearings	2
2-18	R0200589-00	Right swing arm weldment	1
2-19	R0200533-00	Bolt M10×50	1
2-20	R0200395-00	Nylon washer	2
2-21	R0200461-00	Sleeve	1
2-22	R0200468-00	Square rod	1
2-23	R0200680-00	Knob bolt	1
2-24	R0200698-00	Spring	1
2-25	R0200444-00	Mounting plate	1
2-26	R0200539-00	Nut M10	2
2-27	R0200537-00	Bolt M10×45	1
2-28	R0200438-00	Right switch mounting plate	1
2-29	R0200366-00	Parking switch	1
2-30	R0200380-00	Bolt assembly	6

ITEM NO.	PART NO.	DESCRIPTION	QTY
2-31	R0200362-00	Linkage	1
2-32	R0200547-00	Washer	4
2-33	R0200381-00	Rod end	1
2-34	R0200382-00	Nut M6	1
2-35	R0200470-00	Adjustment screw	1
2-36	R0200383-00	Nut M6	1
2-37	R0200361-00	Rod end (Left hand thread)	1
2-38	R0200384-00	Bolt M6×20	1
2-39	R0200385-00	Bolt M6×30	1
2-40	R0200386-00	Spacer	1
2-41	R0200358-00	Linkage	1
2-42	R0200387-00	Rod end	1
2-43	R0200519-00	Nut M8	1
2-44	R0200471-00	Adjustment Screw	1
2-45	R0200563-00	Nut M8	1
2-46	R0200394-00	Rod end	1
2-47	R0200396-00	Bolt M8×25	1
2-48	R0200397-00	Bolt M8×55	1
2-49	R0200548-00	Washer	1
2-50	R0200681-00	Damper	1

ITEM NO.	PART NO.	DESCRIPTION	QTY
3-1	R0200398-00	Bolt M8×25	1
3-2	R0200540-00	Spring washer	1
3-3	R0200541-00	Large washer	2
3-4	R0200389-00	Spacer collar	2
3-5	R0200585-00	Sleeve	1
3-6	R0200434-00	Spring hanging plate	2
3-7	R0200356-00	Return spring	1
3-8	R0200388-00	Nylon washer	1
3-9	R0200532-00	Bolt assembly	2
3-10	R0200442-00	Right rotating plate	1
3-11	R0200432-00	Limit plate	1
3-12	R0200605-00	Right fixed plate weldment	1
3-13	R0200565-00	Screws ST4.2×10	2
3-14	R0200433-00	Sensor connection plate AC	1
3-15	R0200354-00	Speed sensor	1


LEFT CONTROL ARM



ITEM NO.	PART NO.	DESCRIPTION	QTY
4-1	R0200763-00	Key	0
4-2	R0200728-00	4" LCD Display	1
4-3	R0200458-00	Left console	1
4-4	R0200380-00	Bolt assembly	6
4-5	R0200681-00	Damper	1
4-6	R0200548-00	Washer	1
4-7	R0200520-00	Lock nut M8	11
4-8	R0200514-00	Lock nut M10	4
4-9	R0200457-00	Console plate	1
4-10	R0200483-00	Left return assembly	1
4-11	R0200518-00	Lock nut M6	2
4-12	R0200564-00	Screw M6×6	1
4-13	R0200592-00	Left swing arm weldment	1
4-14	R0200362-00	Linkage	1
4-15	R0200384-00	Bolt M6×20	1
4-16	R0200381-00	Rod end M6	1
4-17	R0200382-00	Nut M6	1
4-18	R0200470-00	Adjustment screw	1
4-19	R0200383-00	Nut M6	1
4-20	R0200361-00	Rod end 6 (Left hand thread)	1
4-21	R0200385-00	Bolt M6×30	1
4-22	R0200547-00	Washer	4
4-23	R0200358-00	Linkage	1
4-24	R0200396-00	Bolt M8×25	1
4-25	R0200387-00	Rod end M8	1
4-26	R0200471-00	Screw	1
4-27	R0200563-00	Nut M8	1
4-28	R0200394-00	Rod end M8	1
4-29	R0200397-00	Bolt M8×55	1
4-30	R0200386-00	Spacer	1


ITEM NO.	PART NO.	DESCRIPTION	QTY
4-31	R0200535-00	Bolt M8×30	1
4-32	R0200519-00	Washer	2
4-33	R0200366-00	Parking switch	1
4-34	R0200437-00	Left switch mounting plate	1
4-35	R0200527-00	Bolt M8×25	7
4-36	R0200680-00	Knob bolt	1
4-37	R0200698-00	Compression spring	1
4-38	R0200444-00	Mounting plate	1
4-39	R0200539-00	Nut M10	2
4-40	R0200614-00	Bearings	2
4-41	R0200537-00	Bolt M10×45	1
4-42	R0200533-00	Bolt M10×50	1
4-43	R0200596-00	Shaft weldment	1
4-44	R0200468-00	Square rod	1
4-45	R0200461-00	Sleeve	1
4-46	R0200395-00	Nylon washer	2
4-47	R0200506-00	Bolt M10×25	3
4-48	R0200738-00	Ignition Switch (with key)	1

LEFT RETURN ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
5-1	R0200398-00	Bolt M8×25	1
5-2	R0200540-00	Lock washer	1
5-3	R0200541-00	Large washer	2
5-4	R0200389-00	Spacer collar	2
5-5	R0200434-00	Spring hanging plate	2
5-6	R0200356-00	Return spring	1
5-7	R0200585-00	Sleeve	1
5-8	R0200388-00	Nylon washer	1
5-9	R0200440-00	Left rotating plate	1
5-10	R0200532-00	Bolt assembly	4
5-11	R0200432-00	Limit plate	1
5-12	R0200603-00	Left fixed plate weldment	1
5-13	R0200565-00	Screws ST4.2×10	1
5-14	R0200433-00	Accelerator connection plate	1
5-15	R0200354-00	Accelerator sensor	1

DECKLIFT ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
6-1	R0200504-00	Bolt M10×70	2
6-2	R0200502-00	Washer	2
6-3	R0200672-00	Spring assembly	2
6-4	R0200595-00	Spring nut	1
6-5	R0200598-00	Spring	1
6-6	R0200515-00	Lock nut M12	6
6-7	R0200559-00	Nut M12	4
6-8	R0200700-00	Collar	4
6-9	R0200699-00	Trunion	4
6-10	R0200707-00	Outer mounting plate	4
6-11	R0200560-00	Bolt M8×40	8
6-12	R0200542-00	Bolt M12×45	1
6-13	R0200543-00	Washer	2
6-14	R0200713-00	Linear actuator	1
6-15	R0200497-00	Bolt M12×60	1
6-16	R0200706-00	Inner mounting plate	4
6-17	R0200496-00	Lock nut M8	8
6-18	R0200712-00	Rear shaft weldment	1
6-19	R0200737-00	Collar	4
6-20	R0200503-00	Bolt M10×55	2
6-21	R0200694-00	Front shaft weldment	1
6-22	R0200702-00	Eyebolt	4
6-23	R0200701-00	Spacer	4
6-24	R0200514-00	Lock nut M10	4
6-25	R0200521-00	Lock nut M10	8
6-26	R0200515-00	Lock nut M12	7
6-27	R0200704-00	Connection plate	1
6-28	R0200616-00	Spacer	2
6-29	R0200586-00	Shaft mount	4
6-30	R0200525-00	Bolt M10×50	8
6-31	R0200516-00	Bolt M12×45	2

BATTERY COVER ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
7-1	R0200607-00	Upper cover plate weldment	1
7-2	R0200399-00	Rotary tongue lock	1
7-3	R0200621-00	Rubber strip	1.4
7-4	R0200526-00	Bolt M8×20	10
7-5	R0200380-00	Bolt assembly	6
7-6	R0200619-00	Rubber strip	1.2
7-7	R0200496-00	Lock nut M8	1
7-8	R0200530-00	Screw M5×30	2
7-9	R0200448-00	Left side plate	1
7-10	R0200580-00	Spacer	2
7-11	R0200545-00	Washer	2
7-12	R0200538-00	Spring washer	2
7-13	R0200511-00	Nut M5	2
7-14	R0200548-00	Washer	11
7-15	R0200400-00	Gas shock	1
7-16	R0200396-00	Bolt M8x25	2
7-17	R0200451-00	Front plate	1
7-18	R0200520-00	Lock nut M8	13
7-19	R0200384-00	Bolt M6×20	2
7-20	R0200351-00	Power resistor	1
7-21	R0200518-00	Lock nut M6	6
7-22	R0200447-00	Right side plate	1
7-23	R0200547-00	Washer	6
7-24	R0200546-00	Screw	4
7-25	R0200729-00	Charger plug w/wire	1
7-26	R0200446-00	Rear cover	1

CONTROL BOX ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
8-1	R0200535-00	Bolt M8×30	8
8-2	R0200548-00	Washer	8
8-3	R0200393-00	Washer	8
8-4	R0200392-00	Bushing	8
8-5	R0200534-00	Bolt assembly	8
8-6	R0200620-00	Thin bumper strip	1.8 m
8-7	R0200520-00	Lock nut M8	1
8-8	R0200579-00	Controller box	4
8-9	R0200716-00	Blade controller assembly	1
8-10	R0200715-00	Drive controller assembly	1
8-11	R0200376-00	Knob bolt	1
8-12	R0200578-00	Controller box cover	2

ROLL OVER PROTECTIVE STRUCTURE




ITEM NO.	PART NO.	DESCRIPTION	QTY
9-1	R0200593-00	Upper ROPS weldment	1
9-2	R0200401-00	Bolt M12×80	6
9-3	R0200402-00	Lock spring	2
9-4	R0200345-00	Pin	2
9-5	R0200403-00	Spring	2
9-6	R0200588-00	Lower ROPS tube	2
9-7	R0200369-00	Lock nut M12	6
9-8	R0200404-00	Washer	4
9-9	R0200469-00	Pin clevis	2

MOWER DECK ASSEMBLY




60" MOWER DECK ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
10-1	R0200714-00	Motor blade	3
10-2	R0200581-00	Deck housing	1
10-3	R0200693-00	Blade collar	3
10-4	R0200339-00	Washer	9
10-5	R0200703-00	20.5" Blade	3
10-6	R0200365-00	Blade washer	3
10-7	R0200364-00	Bolt M16×70	3
10-8	R0200502-00	Washer	18
10-9	R0200499-00	Spring washer	18
10-10	R0200501-00	Bolt M10×25	18
10-11	R0200369-00	Lock nut M12	3
10-12	R0200687-00	Roller shaft	1
10-13	R0200363-00	Roller wheels	4
10-14	R0200360-00	Bolt M12×190	1
10-15	R0200692-00	Roller shaft	2
10-16	R0200691-00	Roller shaft	2
10-17	R0200359-00	Bolt M12×120	2
10-18	R0200671-00	Deflector rubber assembly	1
10-19	R0200710-00	Rubber bumper	2
10-20	R0200518-00	Lock nut M6	3
10-21	R0200520-00	Lock nut M8	4
10-22	R0200496-00	Lock nut M8	2
10-23	R0200465-00	Air plate 1	1
10-24	R0200526-00	Bolt M8×20	2
10-25	R0200550-00	Bolt M10×30	2
10-26	R0200528-00	Bolt M8×30	5
10-27	R0200462-00	Lower bracket deflector	1
10-28	R0200617-00	Deflector rubber	1
10-29	R0200575-00	Upper bracket deflector	1
10-30	R0200520-00	Lock nut M8	5
10-31	R0200521-00	Lock nut	2
10-32	R0200398-00	Bolt M8×25	2
10-33	R0200591-00	Connection pin weldment	2
10-34	R0200357-00	Deck mounting rod assy	2
10-35	R0200405-00	Deck mounting rod	1
10-36	R0200684-00	Grease zerk fitting M6	1
10-37	R0200406-00	Nut M16	1
10-38	R0200407-00	Rod end M16	1
10-39	R0200408-00	Bolt M16×60	1
10-40	R0200409-00	Lock nut M16	1
10-41	R0200548-00	Washer	5
10-42	R0200507-00	Bolt M16×20	3
10-43	R0200412-00	Hose clamp	3
10-44	S0300008-00	Nut, clip-on M6	3

SEAT ASSEMBLY



ITEM NO.	PART NO.	DESCRIPTION	QTY
11-1	R0200307-00	Suspension Seat	1
11-2	R0200452-00	Seat plate	1
11-3	R0200410-00	Leash	1
11-4	R0200501-00	Bolt M10×25	2
11-5	R0200587-00	Sleeve	2
11-6	R0200377-00	Rubber bumper	2
11-7	R0200529-00	Washer	1
11-8	R0200469-00	Pin clevis	1
11-9	R0200514-00	Lock nut M10	4
11-10	R0200502-00	Washer	4
11-11	R0200380-00	Bolt assembly	8
11-12	R0200709-00	Rubber isolator	4
11-13	R0200454-00	Washer	4
11-14	R0200512-00	Bolt M10×80	4
11-15	R0200521-00	Lock nut M10	2
11-16	R0200459-00	Seat base	1
11-17	R0200571-00	Nut 5/16-18	4
11-18	R0200548-00	Washer	4

ELECTRICAL COMPONENTS



ITEM NO.	PART NO.	DESCRIPTION	QTY
12-1	R0200730-00	Wiring harness assembly	1
12-2	R0200731-00	Blade controller cable positive	2
12-3	R0200732-00	Blade controller cable negative	2
12-4	R0200733-00	Machine power harness	1
12-5	R0200734-00	Drive controller cable positive	1
12-6	R0200735-00	Drive controller cable negative	1
12-7	R0200665-00	Lithium battery 13.8 KWH	1
12-8	R0200144-00	Charger 15A 1500WATTS	1
12-9	R0200847-00	Fuse, 20A Maxi (Main)	1
12-10	R0200848-00	Fuse, 40A Maxi (Decklift)	1

GREENWORKS

COMMERCIAL

**Greenworks Tools
PO Box 1238
Mooreville, NC 28115**

TOLL-FREE HELPLINE: 1-855-470-4267



Printed in China on 100% Recycled Paper