


# GREENWORKS

## COMMERCIAL

### Zero Turn Mower 2501702 (Model No.GZM52R)



#### Parts Manual

**TOLL-FREE HELPLINE: 1-855-470-4267**

[www.GreenworksCommercial.com](http://www.GreenworksCommercial.com)

---


 Read all safety rules and instructions carefully before operating this tool.

# CONTENTS

|                                     |    |
|-------------------------------------|----|
| FRAME ASSEMBLY.....                 | 3  |
| RIGHT CONTROL ARM.....              | 6  |
| RIGHT RETURN ASSEMBLY.....          | 9  |
| LEFT CONTROL ARM.....               | 11 |
| LEFT RETURN ASSEMBLY.....           | 14 |
| DECKLIFT ASSEMBLY.....              | 16 |
| BATTERY COVER ASSEMBLY.....         | 18 |
| CONTROLLER BOX ASSEMBLY.....        | 20 |
| ROLL OVER PROTECTIVE STRUCTURE..... | 22 |
| MOWER DECK ASSEMBLY.....            | 24 |
| SEAT ASSEMBLY.....                  | 27 |
| ELECTRICAL COMPONENTS.....          | 29 |

**NOTE:** ILLUSTRATIONS MAY OR MAY NOT REPRESENT THE ACTUAL ASSEMBLIES AND IT IS NOT RECOMMENDED TO USE THIS MANUAL AS A GUIDE TO ASSEMBLE OR DISASSEMBLE THE MOWER.


RIGHT CONTROL ARM



| ITEM NO. | PART NO.    | DESCRIPTION            | QTY |
|----------|-------------|------------------------|-----|
| 1-1      | R0200486-00 | Frame weldment         | 1   |
| 1-2      | R0200464-00 | Floor plate            | 1   |
| 1-3      | R0200376-00 | Knob bolt              | 5   |
| 1-4      | R0200377-00 | Rubber pad             | 4   |
| 1-5      | R0200467-00 | Pointer                | 1   |
| 1-6      | R0200509-00 | Bolt M10×25            | 6   |
| 1-7      | R0200514-00 | Lock nut M10           | 2   |
| 1-8      | R0200488-00 | Right console assembly | 1   |
| 1-9      | R0200481-00 | Control box assembly   | 1   |
| 1-10     | R0200583-00 | Right fender           | 1   |
| 1-11     | R0200449-00 | Rear baffle            | 1   |
| 1-12     | R0200445-00 | Lower back cover       | 1   |
| 1-13     | R0200520-00 | Lock nut M8            | 8   |
| 1-14     | R0200548-00 | Washer                 | 4   |
| 1-15     | R0200495-00 | Bolt M10×40            | 2   |
| 1-16     | R0200473-00 | Manual release plate   | 2   |
| 1-17     | R0200539-00 | Nut M10                | 2   |
| 1-18     | R0200532-00 | Bolt assembly          | 6   |
| 1-19     | R0200526-00 | Bolt M8×20             | 4   |
| 1-20     | R0200615-00 | Upper bracket weldment | 2   |
| 1-21     | R0200527-00 | Bolt M8×25             | 4   |
| 1-22     | R0200582-00 | Left fender            | 1   |
| 1-23     | R0200534-00 | Bolt assembly          | 12  |
| 1-24     | R0200549-00 | Nut M8                 | 6   |
| 1-25     | R0200669-00 | Motor drive assembly   | 2   |
| 1-26     | R0200544-00 | Bolt M10×50            | 8   |
| 1-27     | R0200499-00 | Spring washer          | 8   |
| 1-28     | R0200502-00 | Washer                 | 10  |
| 1-29     | R0200431-00 | Spacer, Motor mount    | 4   |
| 1-30     | R0200485-00 | Left console assembly  | 1   |

| ITEM NO. | PART NO.    | DESCRIPTION          | QTY |
|----------|-------------|----------------------|-----|
| 1-31     | R0200551-00 | Bolt M5×16           | 2   |
| 1-32     | R0200684-00 | Zerk Fitting M6      | 2   |
| 1-33     | R0200668-00 | Light LED            | 1   |
| 1-34     | R0200545-00 | Washer               | 2   |
| 1-35     | R0200538-00 | Spring washer        | 2   |
| 1-36     | R0200511-00 | Nut M5               | 2   |
| 1-37     | R0200685-00 | Caster weldment      | 2   |
| 1-38     | R0200375-00 | Oil seal             | 2   |
| 1-39     | R0200374-00 | Bearing              | 4   |
| 1-40     | R0200373-00 | Spring washer        | 6   |
| 1-41     | R0200372-00 | Lock nut M20         | 2   |
| 1-42     | R0200686-00 | Dust cap             | 2   |
| 1-43     | R0200411-00 | Front wheel assembly | 2   |
| 1-44     | R0200371-00 | Bolt M12×236         | 1   |
| 1-45     | R0200355-00 | Front wheel          | 1   |
| 1-46     | R0200369-00 | Lock nut M12         | 2   |
| 1-47     | R0200352-00 | Rear wheel           | 2   |
| 1-48     | R0200368-00 | Nut 1/2-20unf        | 8   |
| 1-49     | R0200378-00 | Spring washer        | 4   |
| 1-50     | R0200509-00 | Bolt M10×25          | 4   |
| 1-51     | R0200677-00 | Lever assy           | 2   |

# RIGHT CONTROL ARM




| ITEM NO. | PART NO.    | DESCRIPTION                     | QTY |
|----------|-------------|---------------------------------|-----|
| 2-1      | R0200721-00 | Blade high and low speed switch | 1   |
| 2-2      | R0200717-00 | PTO switch                      | 1   |
| 2-3      | R0200455-00 | Right control cover             | 1   |
| 2-4      | R0200719-00 | High and low drive switch       | 1   |
| 2-5      | R0200718-00 | Linear actuator                 | 1   |
| 2-6      | R0200482-00 | Right return assy               | 1   |
| 2-7      | R0200564-00 | Screw M6×6                      | 1   |
| 2-8      | R0200596-00 | Shaft weldment                  | 1   |
| 2-9      | R0200518-00 | Lock nut M6                     | 2   |
| 2-10     | R0200527-00 | Bolt M8×25                      | 7   |
| 2-11     | R0200520-00 | Lock nut M8                     | 11  |
| 2-12     | R0200506-00 | Bolt M10×25                     | 3   |
| 2-13     | R0200457-00 | Console plate                   | 1   |
| 2-14     | R0200514-00 | Lock nut M10                    | 4   |
| 2-15     | R0200535-00 | Bolt M8×30                      | 1   |
| 2-16     | R0200519-00 | Nut M8                          | 1   |
| 2-17     | R0200614-00 | Bearings                        | 2   |
| 2-18     | R0200589-00 | Right swing arm weldment        | 1   |
| 2-19     | R0200533-00 | Bolt M10×50                     | 1   |
| 2-20     | R0200395-00 | Nylon washer                    | 2   |
| 2-21     | R0200461-00 | Sleeve                          | 1   |
| 2-22     | R0200468-00 | Square rod                      | 1   |
| 2-23     | R0200680-00 | Knob bolt                       | 1   |
| 2-24     | R0200698-00 | Spring                          | 1   |
| 2-25     | R0200444-00 | Mounting plate                  | 1   |
| 2-26     | R0200539-00 | Nut M10                         | 2   |
| 2-27     | R0200537-00 | Bolt M10×45                     | 1   |
| 2-28     | R0200438-00 | Right switch mounting plate     | 1   |
| 2-29     | R0200366-00 | Parking switch                  | 1   |
| 2-30     | R0200380-00 | Bolt assembly                   | 6   |
| 2-31     | R0200362-00 | Linkage                         | 1   |
| 2-32     | R0200547-00 | Washer                          | 4   |

| ITEM NO. | PART NO.    | DESCRIPTION                  | QTY |
|----------|-------------|------------------------------|-----|
| 2-33     | R0200381-00 | Rod end                      | 1   |
| 2-34     | R0200382-00 | Nut M6                       | 1   |
| 2-35     | R0200470-00 | Adjustment screw             | 1   |
| 2-36     | R0200383-00 | Nut M6                       | 1   |
| 2-37     | R0200361-00 | Rod end ( Left hand thread ) | 1   |
| 2-38     | R0200384-00 | Bolt M6×20                   | 1   |
| 2-39     | R0200385-00 | Bolt M6×30                   | 1   |
| 2-40     | R0200386-00 | Spacer                       | 1   |
| 2-41     | R0200358-00 | Linkage                      | 1   |
| 2-42     | R0200387-00 | Rod end                      | 1   |
| 2-43     | R0200519-00 | Nut M8                       | 1   |
| 2-44     | R0200471-00 | Adjustment Screw             | 1   |
| 2-45     | R0200563-00 | Nut M8                       | 1   |
| 2-46     | R0200394-00 | Rod end                      | 1   |
| 2-47     | R0200396-00 | Bolt M8×25                   | 1   |
| 2-48     | R0200397-00 | Bolt M8×55                   | 1   |
| 2-49     | R0200548-00 | Washer                       | 1   |
| 2-50     | R0200681-00 | Damper                       | 1   |




## RIGHT RETURN ASSEMBLY



| ITEM NO. | PART NO.    | DESCRIPTION                | QTY |
|----------|-------------|----------------------------|-----|
| 3-1      | R0200398-00 | Bolt M8×25                 | 1   |
| 3-2      | R0200540-00 | Spring washer              | 1   |
| 3-3      | R0200541-00 | Large washer               | 2   |
| 3-4      | R0200389-00 | Spacer collar              | 2   |
| 3-5      | R0200585-00 | Sleeve                     | 1   |
| 3-6      | R0200434-00 | Spring hanging plate       | 2   |
| 3-7      | R0200356-00 | Return spring              | 1   |
| 3-8      | R0200388-00 | Nylon washer               | 1   |
| 3-9      | R0200532-00 | Bolt assembly              | 2   |
| 3-10     | R0200442-00 | Right rotating plate       | 1   |
| 3-11     | R0200432-00 | Limit plate                | 1   |
| 3-12     | R0200605-00 | Right fixed plate weldment | 1   |
| 3-13     | R0200565-00 | Screws ST4.2×10            | 2   |
| 3-14     | R0200433-00 | Sensor connection plate AC | 1   |
| 3-15     | R0200354-00 | Speed sensor               | 1   |


# LEFT CONTROL ARM



| ITEM NO. | PART NO.    | DESCRIPTION                  | QTY |
|----------|-------------|------------------------------|-----|
| 4-1      | R0200763-00 | Key                          | 1   |
| 4-2      | R0200728-00 | 4" LCD Display               | 1   |
| 4-3      | R0200458-00 | Cover                        | 1   |
| 4-4      | R0200380-00 | Bolt assembly                | 6   |
| 4-5      | R0200681-00 | Damper                       | 1   |
| 4-6      | R0200548-00 | Washer                       | 1   |
| 4-7      | R0200520-00 | Lock nut M8                  | 11  |
| 4-8      | R0200514-00 | Lock nut M10                 | 4   |
| 4-9      | R0200457-00 | Console plate                | 1   |
| 4-10     | R0200483-00 | Left return assembly         | 1   |
| 4-11     | R0200518-00 | Lock nut M6                  | 2   |
| 4-12     | R0200564-00 | Screw M6×6                   | 1   |
| 4-13     | R0200592-00 | Left swing arm weldment      | 1   |
| 4-14     | R0200362-00 | Linkage                      | 1   |
| 4-15     | R0200384-00 | Bolt M6×20                   | 1   |
| 4-16     | R0200381-00 | Joint bearing 6              | 1   |
| 4-17     | R0200382-00 | Nut M6                       | 1   |
| 4-18     | R0200470-00 | Adjustment screw             | 1   |
| 4-19     | R0200383-00 | Nut M6                       | 1   |
| 4-20     | R0200361-00 | Rod end 6 (Left hand thread) | 1   |
| 4-21     | R0200385-00 | Bolt M6×30                   | 1   |
| 4-22     | R0200547-00 | Washer                       | 4   |
| 4-23     | R0200358-00 | Linkage                      | 1   |
| 4-24     | R0200396-00 | Bolt M8×25                   | 1   |
| 4-25     | R0200387-00 | Rod end M8                   | 1   |
| 4-26     | R0200471-00 | Screw                        | 1   |
| 4-27     | R0200563-00 | Nut M8                       | 1   |
| 4-28     | R0200394-00 | Rod end M8                   | 1   |
| 4-29     | R0200397-00 | Bolt M8×55                   | 1   |
| 4-30     | R0200386-00 | Spacer                       | 1   |


| ITEM NO. | PART NO.    | DESCRIPTION                | QTY |
|----------|-------------|----------------------------|-----|
| 4-31     | R0200535-00 | Bolt M8×30                 | 1   |
| 4-32     | R0200519-00 | Washer                     | 2   |
| 4-33     | R0200366-00 | Parking switch             | 1   |
| 4-34     | R0200437-00 | Left switch mounting plate | 1   |
| 4-35     | R0200527-00 | Bolt M8×25                 | 7   |
| 4-36     | R0200680-00 | Knob bolt                  | 1   |
| 4-37     | R0200698-00 | Compression spring         | 1   |
| 4-38     | R0200444-00 | Mounting plate             | 1   |
| 4-39     | R0200539-00 | Nut M10                    | 2   |
| 4-40     | R0200614-00 | Bearings                   | 2   |
| 4-41     | R0200537-00 | Bolt M10×45                | 1   |
| 4-42     | R0200533-00 | Bolt M10×50                | 1   |
| 4-43     | R0200596-00 | Shaft weldment             | 1   |
| 4-44     | R0200468-00 | Square rod                 | 1   |
| 4-45     | R0200461-00 | Sleeve                     | 1   |
| 4-46     | R0200395-00 | Nylon washer               | 2   |
| 4-47     | R0200506-00 | Bolt M10×25                | 3   |
| 4-48     | R0200430-00 | Ignition Switch (with key) | 1   |

## LEFT RETURN ASSEMBLY



| ITEM NO. | PART NO.    | DESCRIPTION                  | QTY |
|----------|-------------|------------------------------|-----|
| 5-1      | R0200398-00 | Bolts M8×25                  | 1   |
| 5-2      | R0200540-00 | Lock washer                  | 1   |
| 5-3      | R0200541-00 | Large washer                 | 2   |
| 5-4      | R0200389-00 | Spacer collar                | 2   |
| 5-5      | R0200434-00 | Spring hanging plate         | 2   |
| 5-6      | R0200356-00 | Return spring                | 1   |
| 5-7      | R0200585-00 | Sleeve                       | 1   |
| 5-8      | R0200388-00 | Nylon washer                 | 1   |
| 5-9      | R0200440-00 | Left rotating plate          | 1   |
| 5-10     | R0200532-00 | Bolt assembly                | 4   |
| 5-11     | R0200432-00 | Limit plate                  | 1   |
| 5-12     | R0200603-00 | Left fixed plate weldment    | 1   |
| 5-13     | R0200565-00 | Screws ST4.2×10              | 1   |
| 5-14     | R0200433-00 | Accelerator connection plate | 1   |
| 5-15     | R0200354-00 | Accelerator sensor           | 1   |


# DECKLIFT ASSEMBLY






| ITEM NO. | PART NO.    | DESCRIPTION          | QTY |
|----------|-------------|----------------------|-----|
| 6-1      | R0200504-00 | Bolt M10×70          | 2   |
| 6-2      | R0200502-00 | Washer               | 2   |
| 6-3      | R0200672-00 | Spring assembly      | 2   |
| 6-4      | R0200595-00 | Spring nut           | 1   |
| 6-5      | R0200598-00 | Spring               | 1   |
| 6-6      | R0200515-00 | Lock nut M12         | 6   |
| 6-7      | R0200559-00 | Nut M12              | 4   |
| 6-8      | R0200700-00 | Collar               | 4   |
| 6-9      | R0200699-00 | Trunion              | 4   |
| 6-10     | R0200707-00 | Outer mounting plate | 4   |
| 6-11     | R0200560-00 | Bolts M8×40          | 8   |
| 6-12     | R0200542-00 | Bolt M12×45          | 1   |
| 6-13     | R0200543-00 | Washer               | 2   |
| 6-14     | R0200713-00 | Linear actuator      | 1   |
| 6-15     | R0200497-00 | Bolt M12×60          | 1   |
| 6-16     | R0200706-00 | Inner mounting plate | 4   |
| 6-17     | R0200496-00 | Lock nut M8          | 8   |
| 6-18     | R0200712-00 | Rear shaft weldment  | 1   |
| 6-19     | R0200737-00 | Collar               | 4   |
| 6-20     | R0200503-00 | Bolts M10×55         | 2   |
| 6-21     | R0200694-00 | Front shaft weldment | 1   |
| 6-22     | R0200702-00 | Eyebolt              | 4   |
| 6-23     | R0200701-00 | Spacer               | 4   |
| 6-24     | R0200514-00 | Lock nut M10         | 4   |
| 6-25     | R0200521-00 | Lock nut M10         | 8   |
| 6-26     | R0200515-00 | Lock nut M12         | 7   |
| 6-27     | R0200704-00 | Connection plate     | 1   |
| 6-28     | R0200616-00 | Spacer               | 2   |
| 6-29     | R0200586-00 | Shaft mount          | 4   |
| 6-30     | R0200525-00 | Bolt M10×50          | 8   |
| 6-31     | R0200516-00 | Bolts M12×45         | 2   |

BATTERY COVER ASSEMBLY




| ITEM NO. | PART NO.    | DESCRIPTION                | QTY |
|----------|-------------|----------------------------|-----|
| 7-1      | R0200607-00 | Upper cover plate weldment | 1   |
| 7-2      | R0200399-00 | Rotary tongue lock         | 1   |
| 7-3      | R0200621-00 | Rubber strip               | 1.4 |
| 7-4      | R0200526-00 | Bolt M8×20                 | 10  |
| 7-5      | R0200380-00 | Bolt assembly              | 6   |
| 7-6      | R0200619-00 | Rubber strip               | 1.2 |
| 7-7      | R0200496-00 | Lock nut M8                | 1   |
| 7-8      | R0200530-00 | Screw M5×30                | 2   |
| 7-9      | R0200448-00 | Left side plate            | 1   |
| 7-10     | R0200580-00 | Spacer                     | 2   |
| 7-11     | R0200545-00 | Washer                     | 2   |
| 7-12     | R0200538-00 | Spring washer              | 2   |
| 7-13     | R0200511-00 | Nut M5                     | 2   |
| 7-14     | R0200548-00 | Washer                     | 11  |
| 7-15     | R0200400-00 | Gas shock                  | 1   |
| 7-16     | R0200396-00 | Bolt M8×25                 | 2   |
| 7-17     | R0200451-00 | Front plate                | 1   |
| 7-18     | R0200520-00 | Lock nut M8                | 13  |
| 7-19     | R0200384-00 | Bolt M6×20                 | 2   |
| 7-20     | R0200351-00 | Power resistor             | 1   |
| 7-21     | R0200518-00 | Lock nut M6                | 6   |
| 7-22     | R0200447-00 | Right side plate           | 1   |
| 7-23     | R0200547-00 | Washer                     | 6   |
| 7-24     | R0200546-00 | Screw                      | 4   |
| 7-25     | R0200729-00 | Charger plug w/wire        | 1   |
| 7-26     | R0200446-00 | Rear cover                 | 1   |

# CONTROL BOX ASSEMBLY




| ITEM NO. | PART NO.    | DESCRIPTION               | QTY   |
|----------|-------------|---------------------------|-------|
| 8-1      | R0200535-00 | Bolt M8×30                | 8     |
| 8-2      | R0200548-00 | Washer                    | 8     |
| 8-3      | R0200393-00 | Washer                    | 8     |
| 8-4      | R0200392-00 | Bushing                   | 8     |
| 8-5      | R0200534-00 | Bolt assembly             | 8     |
| 8-6      | R0200620-00 | Thin bumper strip         | 1     |
| 8-7      | R0200520-00 | Lock nut M8               | 1     |
| 8-8      | R0200579-00 | Controller box            | 4     |
| 8-9      | R0200716-00 | Blade controller assembly | 1     |
| 8-10     | R0200715-00 | Drive controller assembly | 1.8 m |
| 8-11     | R0200376-00 | Knob bolt                 | 1     |
| 8-12     | R0200578-00 | Controller box cover      | 2     |

# ROLL OVER PROTECTIVE STRUCTURE




| ITEM NO. | PART NO.    | DESCRIPTION         | QTY |
|----------|-------------|---------------------|-----|
| 9-1      | R0200593-00 | Upper ROPS weldment | 1   |
| 9-2      | R0200401-00 | Bolt M12×80         | 6   |
| 9-3      | R0200402-00 | Lock spring         | 2   |
| 9-4      | R0200345-00 | Pin                 | 2   |
| 9-5      | R0200403-00 | Spring              | 2   |
| 9-6      | R0200588-00 | Lower ROPS tube     | 2   |
| 9-7      | R0200369-00 | Lock nut M12        | 6   |
| 9-8      | R0200404-00 | Washer              | 4   |
| 9-9      | R0200469-00 | Pin clevis          | 2   |

# MOWER DECK ASSEMBLY






# 52" MOWER DECK ASSEMBLY




| ITEM NO. | PART NO.    | DESCRIPTION               | QTY |
|----------|-------------|---------------------------|-----|
| 10-1     | R0200714-00 | Motor blade               | 3   |
| 10-2     | R0200584-00 | Deck housing              | 1   |
| 10-3     | R0200693-00 | Blade collar              | 3   |
| 10-4     | R0200339-00 | Washer                    | 9   |
| 10-5     | R0200350-00 | 18" Blade                 | 3   |
| 10-6     | R0200365-00 | Blade washer              | 3   |
| 10-7     | R0200364-00 | Bolt M16×70               | 3   |
| 10-8     | R0200502-00 | Washer                    | 18  |
| 10-9     | R0200499-00 | Spring washer             | 18  |
| 10-10    | R0200501-00 | Bolt M10×25               | 18  |
| 10-11    | R0200369-00 | Lock nut M12              | 3   |
| 10-12    | R0200363-00 | Roller wheels             | 3   |
| 10-13    | R0200692-00 | Roller shaft              | 3   |
| 10-14    | R0200691-00 | Roller shaft              | 3   |
| 10-15    | R0200359-00 | Bolt M12×120              | 3   |
| 10-16    | R0200484-00 | Deflector rubber assembly | 1   |
| 10-17    | R0200710-00 | Rubber bumper             | 2   |
| 10-18    | R0200518-00 | Lock nut M6               | 3   |
| 10-19    | R0200520-00 | Lock nut M8               | 4   |
| 10-20    | R0200496-00 | Lock nut M8               | 2   |
| 10-21    | R0200460-00 | Air plate 1               | 1   |
| 10-22    | R0200526-00 | Bolt M8×20                | 2   |
| 10-23    | R0200550-00 | Bolt M10×30               | 2   |
| 10-24    | R0200528-00 | Bolt M8×30                | 5   |
| 10-25    | R0200462-00 | Lower bracket deflector   | 1   |
| 10-26    | R0200618-00 | Deflector rubber          | 1   |
| 10-27    | R0200575-00 | Upper bracket deflector   | 1   |
| 10-28    | R0200520-00 | Lock nut M8               | 5   |
| 10-29    | R0200521-00 | Lock nut                  | 2   |
| 10-30    | R0200398-00 | Bolt M8×25                | 2   |
| 10-31    | R0200591-00 | Connection pin weldment   | 2   |
| 10-32    | R0200357-00 | Deck mounting rod assy    | 2   |
| 10-33    | R0200405-00 | Deck mounting rod         | 1   |
| 10-34    | R0200684-00 | Grease zerk fitting M6    | 1   |
| 10-35    | R0200406-00 | Nut M16                   | 1   |
| 10-36    | R0200407-00 | Rod end M16               | 1   |
| 10-37    | R0200408-00 | Bolt M16×60               | 1   |
| 10-38    | R0200409-00 | Lock nut M16              | 1   |
| 10-39    | R0200548-00 | Washer                    | 5   |
| 10-40    | R0200507-00 | Bolt M16×20               | 3   |
| 10-41    | R0200412-00 | Hose clamp                | 3   |
| 10-42    | S0300008-00 | Nut, clip-on M6           | 3   |

SEAT ASSEMBLY



| ITEM NO. | PART NO.    | DESCRIPTION     | QTY |
|----------|-------------|-----------------|-----|
| 11-1     | R0200307-00 | Suspension seat | 1   |
| 11-2     | R0200452-00 | Seat plate      | 1   |
| 11-3     | R0200410-00 | Leash           | 1   |
| 11-4     | R0200501-00 | Bolt M10×25     | 2   |
| 11-5     | R0200587-00 | Sleeve          | 2   |
| 11-6     | R0200377-00 | Rubber bumper   | 2   |
| 11-7     | R0200529-00 | Washer          | 1   |
| 11-8     | R0200469-00 | Pin clevis      | 1   |
| 11-9     | R0200514-00 | Lock nut M10    | 4   |
| 11-10    | R0200502-00 | Washer          | 4   |
| 11-11    | R0200380-00 | Bolt assembly   | 8   |
| 11-12    | R0200709-00 | Rubber isolator | 4   |
| 11-13    | R0200454-00 | Washer          | 4   |
| 11-14    | R0200512-00 | Bolt M10×80     | 4   |
| 11-15    | R0200521-00 | Lock nut M10    | 2   |
| 11-16    | R0200459-00 | Seat base       | 1   |
| 11-17    | R0200571-00 | Nut 5/16-18     | 4   |
| 11-18    | R0200548-00 | Washer          | 4   |

ELECTRICAL COMPONENTS



| ITEM NO. | PART NO.    | DESCRIPTION                     | QTY |
|----------|-------------|---------------------------------|-----|
| 12-1     | R0200730-00 | Wiring harness assembly         | 1   |
| 12-2     | R0200731-00 | Blade controller cable positive | 2   |
| 12-3     | R0200732-00 | Blade controller cable negative | 2   |
| 12-4     | R0200733-00 | Machine power harness           | 1   |
| 12-5     | R0200734-00 | Drive controller cable positive | 1   |
| 12-6     | R0200735-00 | Drive controller cable negative | 1   |
| 12-7     | R0200665-00 | Lithium battery 13.8 KWH        | 1   |
| 12-8     | R0200736-00 | Charger 15A 1500WATTS           | 1   |
| 12-9     | R0200847-00 | Fuse, 20A Maxi (Main)           | 1   |
| 12-10    | R0200848-00 | Fuse, 40A Maxi (Decklift)       | 1   |

# **GREENWORKS**

## **COMMERCIAL**

**Greenworks Tools  
PO Box 1238  
Mooresville, NC 28115**

**TOLL-FREE HELPLINE: 1-855-470-4267**



Printed in China on 100% Recycled Paper