



GXV390UT1(DET3)	E-11 RECOIL STARTER
-----------------	---------------------



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	28400-ZE3-W01ZP	STARTER ASSY., RECOIL *R280 *	1	
002	28410-ZE3-W01ZP	CASE COMP., RECOIL STARTER *R280 *	1	
003	28421-ZE3-W01	PULLEY, RECOIL STARTER	1	
004	28422-ZE2-W01	RATCHET, STARTER	2	
005	28441-ZE2-W01	SPRING, FRICTION	1	
006	28442-ZE2-W01	SPRING, STARTER RETURN	1	
007	28443-ZE2-W01	SPRING, RATCHET	2	
008	28444-ZE2-W01	RETAINER, SPRING	1	
009	28461-ZE2-W02	GRIP, STARTER	1	
010	28462-ZE3-W01	ROPE, RECOIL STARTER	1	
011	90004-ZE2-W01	SCREW, CENTER	1	
012	94050-06000	NUT, FLANGE, 6MM	4	


GXV390UT1(DET3)	E-12 FAN COVER
-----------------	----------------



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
002	19610-ZF5-V11ZC	COVER COMP., FAN *R280 *	1	
005	19617-ZF5-V00	BRACKET, FAN COVER	2	
011	90029-888-000	BOLT, FLANGE, 6X16 (CT200)	4	
013	91501-ZF5-V00	COLLAR, FAN COVER	4	

GXV390UT1(DET3)

E-14 CARBURETOR




Ref	Partnumber	Description	GXV390UT1	Serial Numbers	
001	16010-ZE2-015	GASKET SET	1		
002	16011-ZA0-931	VALVE SET, FLOAT	1		
003	16013-Z1C-003	FLOAT SET	1		
004	16015-ZE8-005	CHAMBER SET, FLOAT	1		
005	16016-Z1E-V21	SCREW SET	1	BE86P B	
005	16016-ZH7-W01	SCREW SET, PILOT	1		BE86P A
006	16024-ZE1-811	SCREW SET, DRAIN	1		
007	16028-ZE0-005	SCREW SET	1		
008	16100-Z1E-V21	CARBURETOR ASSY. (BE86P A)	1		1019651
008	16100-Z1E-V22	CARBURETOR ASSY. (BE86P B)	1	1019652	1068884
008	16100-Z5V-801	CARBURETOR ASSY. (BE86W A)	1	1068885	
009	16124-ZE0-005	SCREW, THROTTLE STOP	1		
010	16148-141-881	CAP, CHOKE DUST	1		

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
011	16166-Z1E-V21	NOZZLE, MAIN	1	BE86P B
011	16166-ZF5-V20	NOZZLE, MAIN	1	BE86P A
012	16172-ZE3-W10	COLLAR, SETTING	1	
013	16199-ZE8-000	TUBE, AIR VENT (75MM)	1	
015	16211-Z1E-000	INSULATOR, CARBURETOR	1	
016	16220-ZA0-702	SPACER COMP., CARBURETOR	1	
017	16221-ZF6-800	PACKING, CARBURETOR	1	
018	16223-ZE9-800	PACKING, INSULATOR	1	
019	16953-ZE1-712	LEVER, COCK	1	
020	16954-ZE1-812	PLATE, LEVER SETTING	1	
021	16956-ZE1-811	SPRING, COCK LEVER	1	
022	16957-ZE1-812	PACKING, FUEL COCK	1	
024	93500-030061H	SCREW, PAN, 3X6	2	
025	95002-02080	CLIP, TUBE (B8)	1	
026	99101-ZH80880	JET, MAIN, #88	(1)	BE86P A
026	99101-ZH80900	JET, MAIN, #90	(1)	
026	99101-ZH80920	JET, MAIN, #92	1	BE86P A
026	99101-ZH80920	JET, MAIN, #92	(1)	BE86P B
026	99101-ZH80950	JET, MAIN, #95	1	BE86P B
027	99204-ZE20400	JET SET, PILOT, #40	1	
029	16141-Z0S-003	WASHER, PLAIN (6.2X10.7 DRAIN)	1	


GXV390UT1(DET3)

E-15 AIR CLEANER



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	17210-Z1E-801	ELEMENT COMP., AIR CLEANER	1	1012653
001	17211-ZF5-V01	ELEMENT, AIR CLEANER	1	1012652
002	17218-ZF5-V00	FILTER, OUTER	1	1012652
003	17231-ZF5-V00	COVER, AIR CLEANER	1	
005	17410-Z1E-802	ELBOW COMP., AIR CLEANER	1	1012653
005	17410-ZF5-V00	ELBOW COMP., AIR CLEANER	1	1012652
006	90014-ZE6-000	BOLT, FLANGE, 6X35 (CT200)	1	
007	90325-044-000	NUT, TOOL BOX SETTING	1	
008	91502-ZF5-V00	COLLAR, AIR CLEANER	2	
009	91503-ZF5-V00	COLLAR, AIR CLEANER	1	
010	94050-06000	NUT, FLANGE, 6MM	2	

GXV390UT1(DET3)	E-16 MUFFLER
-----------------	--------------




Ref	Partnumber	Description	GXV390UT1	Serial Numbers	
001	18310-Z1E-010	MUFFLER COMP.	1		
002	18316-ZF5-V00	SEPARATOR, MUFFLER	1		
003	18318-ZE8-000	STAY COMP., MUFFLER	1		
004	18321-ZF5-000	PROTECTOR, MUFFLER	1		
005	18331-ZE2-810	CAP, MUFFLER	1		
006	18331-ZF5-000	PIPE, EX.	1		
007	18333-Z1C-801	GASKET, EX. PIPE	1	1018627	
007	18333-ZE3-800	GASKET, EX. PIPE	1		1018626
009	18382-Z1F-801	GASKET, EX. PIPE	1	1018627	
009	18382-ZE9-800	GASKET, EX. PIPE	1		1018626
010	90031-883-000	BOLT, FLANGE, 8X16	1		
011	90050-ZE1-000	SCREW, TAPPING, 5X8	3		
012	90055-ZE1-000	SCREW, TAPPING, 4X6	3		

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
013	92900-080601B	BOLT, STUD, 8X60	1	
014	92900-080701B	BOLT, STUD, 8X70	1	
015	93500-060060A	SCREW, PAN, 6X6	3	
016	94050-08000	NUT, FLANGE, 8MM	2	
017	94101-06000	WASHER, PLAIN, 6MM	3	
018	95701-0801400	BOLT, FLANGE, 8X14	1	

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
010	17622-888-010	SPONGE, FUEL CAP BREATHER	1	1019651
011	17624-ZE7-000	PACKING, FUEL CAP	1	1019651
012	90455-896-700	WASHER, TANK MOUNTING	4	
013	90471-SB0-000	WASHER, PLAIN, 8MM	2	
015	95002-02080	CLIP, TUBE (B8)	1	1003217
017	95002-70000	CLIP, TUBE (C11)	1	1003217
018	95701-0809500	BOLT, FLANGE, 8X95	2	
019	95002-4080008	CLAMP, TUBE (D8)	1	1003218
020	95002-4105008	CLAMP, TUBE (D10.5)	1	1003218
021	17620-Z0J-800	CAP ASSY., FUEL TANK	1	1019652
022	17636-Z5N-000	GAUGE, FUEL LEVEL	1	1019652

GXV390UT1(DET3)


E-19 FLYWHEEL



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	19511-ZE9-010	FAN, COOLING	1	
003	28450-ZE9-004	PULLEY COMP., STARTER (SCREEN GRID)	1	
007	31110-ZF5-L32	FLYWHEEL COMP. (SEL-4POLE)	1	
010	31630-ZF5-003	COIL ASSY., CHARGE	1	
011	46391-VM0-003	CLIP, BRAKE PIPE (A)	1	
012	90015-883-000	BOLT, FLANGE, 6X28 (CT200)	2	
014	90201-ZE3-790	NUT, SPECIAL, 16MM	1	
014	90201-ZE3-V00	NUT, SPECIAL, 16MM	1	

GXV390UT1(DET3)

E-2 CYLINDER HEAD




Z5V0-E0200

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	12200-Z1E-405	HEAD COMP., CYLINDER	1	
002	12204-ZE2-306	GUIDE, IN. VALVE (O.S.)	1	
003	12205-ZE2-305	GUIDE, EX. VALVE (OS)	1	
004	12216-ZE2-300	CLIP, VALVE GUIDE	2	
005	12251-ZF5-H03	GASKET, CYLINDER HEAD	1	
006	12310-ZE8-000	COVER, HEAD	1	
007	12391-ZE8-000	PACKING, HEAD COVER	1	
008	18345-ZF5-020	COVER, UNDER	1	
009	18347-ZE8-000	STAY COMP., UNDER COVER	1	
010	90003-Z1E-000	BOLT, FLANGE, 10X85	4	
011	90013-883-000	BOLT, FLANGE, 6X12 (CT200)	3	
012	90014-ZE8-000	BOLT, HEAD COVER	1	
013	90042-ZE8-000	BOLT, STUD, 8X131.5	2	

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
014	90401-437-000	WASHER, PLAIN, 10MM	4	
015	90441-ZE2-010	WASHER COMP., HEAD COVER	1	
016	92900-080320B	BOLT, STUD, 8X32	2	
017	94301-12200	DOWEL PIN, 12X20	2	
018	95701-0601200	BOLT, FLANGE, 6X12	1	
019	98079-55876	PLUG, SPARK (BPR5ES) (NGK)	1	


GXV390UT1(DET3)	E-20 IGNITION COIL
-----------------	--------------------



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>	
001	30500-Z1E-013	COIL ASSY., IGNITION	1		1010660
001	30500-Z1E-023	COIL ASSY., IGNITION	1	1010661	1090576
001	30500-Z1E-801	COIL ASSY., IGNITION	1	1090577	
002	30700-ZF5-013	CAP ASSY., NOISE SUPPRESSOR	1		
005	31700-ZE8-003	RECTIFIER ASSY., SILICON	1		
007	31717-ZF5-V00	BRACKET, RECTIFIER	1		
008	32161-404-610	BAND B1, WIRE	1		
010	36101-ZE8-810	CORD, STOP SWITCH	1		
012	46391-VM0-003	CLIP, BRAKE PIPE (A)	2		
014	80101-166-000	GROMMET, WIRE CORD	1		
015	90015-883-000	BOLT, FLANGE, 6X28 (CT200)	2		
018	95701-0603200	BOLT, FLANGE, 6X32	1		

GXV390UT1(DET3)

E-21 STARTER MOTOR




<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	31200-ZF5-L32	MOTOR ASSY., STARTER	1	
002	31206-ZF5-L31	DRIVE ASSY.	1	
003	31216-ZJ1-004	YOKE COMP.	1	
004	31217-ZF5-L31	ARMATURE COMP.	1	
005	31225-ZF5-L31	STOPPER SET, PINION	1	
006	31226-ZF5-L31	BRUSH SET	1	
007	31231-ZJ1-004	HOLDER COMP., BRUSH	1	
008	31237-ZJ1-004	NUT SET, TERMINAL	1	
009	31261-ZF5-L31	BOLT, THROUGH	2	
010	32402-ZF5-V00	CORD, MAGNET SWITCH	1	
011	32411-ZV4-811	COVER, STARTER TERMINAL	1	
012	32412-ZV4-811	COVER, MAGNETIC SWITCHTERMINAL	1	
013	35850-ZF5-V01	SWITCH ASSY., STARTER MAGNETIC	1	

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
014	90407-ZF5-L31	WASHER, THRUST	1	
016	91504-ZF5-V00	COLLAR, DISTANCE	2	
017	94070-06080	NUT-WASHER, 6MM	2	
018	94301-10120	DOWEL PIN, 10X12	2	
019	95701-0803500	BOLT, FLANGE, 8X35	2	
020	96001-0602500	BOLT, FLANGE, 6X25	2	

GXV390UT1(DET3)

E-22 CONTROL (1)




Z5VDE2200B

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
002	16500-ZF5-010	CONTROL ASSY.	1	
004	16551-ZF5-000	ARM, GOVERNOR	1	
005	16555-ZE9-000	ROD, GOVERNOR	1	
006	16556-ZE9-000	ROD, CHOKE	1	
007	16557-ZE8-810	ROD, JOINT	1	
008	16561-ZF5-000	SPRING, GOVERNOR	1	
009	16563-ZE8-000	SPRING, GOVERNOR PRIMARY	1	
010	16576-891-000	HOLDER, CABLE	1	
011	16584-883-300	SPRING, CONTROL ADJUSTING	1	
012	16592-732-700	SPRING, CABLE RETURN	1	
014	16619-ZF5-000	LEVER, CHOKE JOINT	1	
015	35330-ZG1-751	SWITCH ASSY., ENGINE	1	
016	35336-750-003	COVER, SWITCH	1	

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
017	36100-ZE8-003	SWITCH ASSY., ENGINE STOP	1	
022	90013-883-000	BOLT, FLANGE, 6X12 (CT200)	1	
023	90015-ZE5-010	BOLT, GOVERNOR ARM	1	
024	90015-ZE8-000	BOLT, FLANGE, 6MM	1	
025	93500-050200A	SCREW, PAN, 5X20	1	
028	92301-050141A	BOLT, RECESSED, 5X14	1	
029	93500-040140A	SCREW, PAN, 4X14	1	
030	94050-06000	NUT, FLANGE, 6MM	1	
031	94101-06800	WASHER, PLAIN, 6MM	1	
032	94111-04000	WASHER, SPRING, 4MM	1	

GXV390UT1(DET3)	E-28 LABEL
-----------------	------------




Z5VDE2800B

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	87101-ZF5-V01	EMBLEM, TOP COVER (13.0)	1	1015369
001	87101-ZF5-V02	EMBLEM, TOP COVER (GXV390)	1	1015370
002	87516-Z4H-000	MARK, OPERATOR CAUTION (ENGLISH) (MADE I	1	1033848
002	87516-Z4H-010	MARK, OPERATOR CAUTION (ENGLISH) (MADE I	1	1033849
002	87516-Z4H-810	MARK, OPERATOR CAUTION (PICTOGRAPH) (MAD	(1)	1033848
003	87601-ZF5-W30	MARK, TYPE (DET3)	1	
004	99004-21002	WRENCH, BOX (P21)	1	
005	87539-Z0J-000	MARK, EX. CAUTION (ENGLISH)	1	1033849

GXV390UT1(DET3)


E-3 CYLINDER BARREL/OIL PAN



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	11300-Z1E-405	PAN ASSY., OIL	1	
002	11381-ZE9-801	PACKING, OIL PAN	1	
003	12000-Z1E-405	BARREL ASSY., CYLINDER	1	
004	12315-ZF5-000	TUBE, BREATHER	1	
005	12370-ZF5-000	CAP, BREATHER CHAMBER	1	
006	12372-ZE2-300	VALVE, BREATHER	1	
007	12373-ZE8-000	PACKING, BREATHER CAP	1	
010	15130-ZE8-000	COVER, OIL PUMP	1	
011	15131-ZE9-003	O-RING, PUMP COVER	1	
012	15330-ZE8-000	ROTOR COMP., INNER	1	
013	15332-891-003	ROTOR, OIL PUMP OUTER	1	
014	15334-ZE8-010	PLATE, OIL FILTER	1	
016	15335-ZE9-000	RUBBER, OIL RETURN	1	

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
019	15400-ZJ1-004	CARTRIDGE, OIL FILTER (TOYO ROKI)	1	
020	15411-ZF5-W00	BASE, OIL FILTER	1	
022	15421-ZE9-003	SCREEN, OIL FILTER	1	
023	15600-Z5N-800	CAP ASSY., OIL FILLER	1	
024	15625-ZE8-000	PACKING, OIL FILLER CAP	1	
025	15630-Z5N-800	EXTENSION COMP., OIL FILLER	1	
026	16510-ZE3-000	GOVERNOR ASSY.	1	
027	16531-Z0A-000	SLIDER, GOVERNOR	1	
028	16541-ZE8-010	SHAFT, GOVERNOR ARM	1	
029	17240-ZE6-000	COLLAR, EXTENSION	1	
032	90013-883-000	BOLT, FLANGE, 6X12 (CT200)	2	
033	90014-ZE6-000	BOLT, FLANGE, 6X35 (CT200)	1	
034	90018-PN3-000	HOLDER, OIL FILTER	1	
035	90121-952-000	BOLT, FLANGE, 6X25 (CT200)	2	
036	90406-VM6-000	WASHER, THRUST, 8.1MM	1	
037	90602-ZE1-000	CLIP, GOVERNOR HOLDER	1	
038	90701-HC4-000	DOWEL PIN, 8X12	2	
039	91001-ZF5-003	BEARING, RADIAL BALL, 6202	2	
040	91201-Z1C-003	OIL SEAL, 35X52X8 (NOK)	2	
041	91203-952-771	OIL SEAL, 8X14X5	1	
042	91301-ZE9-003	O-RING, 22.1X2.2	1	
043	91302-ZE9-003	O-RING, 11.8X2.4	1	
045	91303-HA0-004	O-RING, 11X1.9 (NOK)	2	
046	91501-ZF5-000	COLLAR, OIL FILTER SETTING	1	
047	92800-20000	BOLT, DRAIN PLUG, 20MM	1	
048	94101-06800	WASHER, PLAIN, 6MM	1	
050	94109-20000	WASHER, DRAIN PLUG, 20MM	1	
051	94251-10000	PIN, LOCK, 10MM	1	
052	95701-0601200	BOLT, FLANGE, 6X12	3	
054	95701-0602500	BOLT, FLANGE, 6X25	1	
055	95701-0804008	BOLT, FLANGE, 8X40	6	
056	95701-0806008	BOLT, FLANGE, 8X60	1	
057	96100-6207300	BEARING, RADIAL BALL, 6207	2	


GXV390UT1(DET3)	E-40 OTHER PARTS
-----------------	------------------



Z5VDE4060D

Ref	Partnumber	Description	GXV390UT1	Serial Numbers
005	87516-Z4H-800	MARK, OPERATOR CAUTION (FRENCH) (MADE IN	1	1033848
010	87516-Z4H-801	MARK, OPERATOR CAUTION (FRENCH) (MADE IN	1	1033849
011	87519-Z4H-000	MARK, OPERATOR CAUTION (PICTOGRAPH)	1	1053395


GXV390UT1(DET3)	E-7 CRANKSHAFT
-----------------	----------------



Z5V0-E0700

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	13310-ZF5-040	CRANKSHAFT COMP.	1	
002	13351-ZF5-030	WEIGHT A, BALANCER	1	
003	13356-ZF5-040	WEIGHT B, BALANCER	1	
004	90417-HA0-000	WASHER, THRUST, 15MM	2	
005	90741-ZE2-000	KEY, SPECIAL WOODRUFF, 25X18	1	

GXV390UT1(DET3)	E-8 PISTON
-----------------	------------




Z5V0-E0800

Ref	Partnumber	Description	GXV390UT1	Serial Numbers
001	13010-Z1C-800	RING SET, PISTON (STD.) (RIKEN)	1	1019651
001	13010-Z5R-004	RING SET, PISTON (STD.) (TEIKOKU)	1	1019652
001	13010-Z5T-003	RING SET, PISTON (STD.) (RIKEN)	1	1019652
001	13011-Z1C-800	RING SET, PISTON (0.25) (RIKEN)	(1)	1019651
001	13011-Z5R-004	RING SET, PISTON (0.25) (TEIKOKU)	(1)	1019652
001	13011-Z5T-003	RING SET, PISTON (0.25) (RIKEN)	(1)	1019652
001	13012-Z1C-800	RING SET, PISTON (0.50) (RIKEN)	(1)	1019651
001	13012-Z5R-004	RING SET, PISTON (0.50) (TEIKOKU)	(1)	1019652
001	13012-Z5T-003	RING SET, PISTON (0.50) (RIKEN)	(1)	1019652
001	13013-Z1C-800	RING SET, PISTON (0.75) (RIKEN)	(1)	1019651
001	13013-Z5R-004	RING SET, PISTON (0.75) (TEIKOKU)	(1)	1019652
001	13013-Z5T-003	RING SET, PISTON (0.75) (RIKEN)	(1)	1019652
002	13101-Z5T-000	PISTON (STD.)	1	1019652

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
002	13101-ZF6-W00	PISTON (STD.)	1	1019651
002	13102-Z5T-000	PISTON (0.25)	(1)	1019652
002	13102-ZF6-W00	PISTON (0.25)	(1)	1019651
002	13103-Z5T-000	PISTON (0.50)	(1)	1019652
002	13103-ZF6-W00	PISTON (0.50)	(1)	1019651
002	13104-Z5T-000	PISTON (0.75)	(1)	1019652
002	13104-ZF6-W00	PISTON (0.75)	(1)	1019651
003	13111-ZF6-000	PIN, PISTON	1	
004	13200-Z1E-000	ROD ASSY., CONNECTING (STD.)	1	
004	13200-Z1E-305	ROD ASSY., CONNECTING(0.25 UNDER SIZE)	(1)	
005	90001-ZE8-000	BOLT, CONNECTING ROD	2	
006	90601-ZE3-000	CLIP, PISTON PIN, 20MM	2	

GXV390UT1(DET3)

E-9 CAMSHAFT



<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
001	12209-ZE8-003	SEAL, VALVE STEM	2	
002	14100-ZF5-020	CAMSHAFT ASSY.	1	
003	14410-Z1C-000	ROD, PUSH	2	
004	14431-ZE2-010	ARM, VALVE ROCKER	2	
005	14441-ZE2-000	LIFTER, VALVE	2	
006	14451-ZE1-013	PIVOT, ROCKER ARM	2	
007	14568-ZE1-000	SPRING, WEIGHT RETURN	1	
008	14711-ZE3-000	VALVE, IN.	1	
009	14721-ZE3-000	VALVE, EX.	1	
010	14751-Z1C-000	SPRING, VALVE	2	
011	14771-ZE2-000	RETAINER, IN. VALVE SPRING	1	
012	14773-ZE2-000	RETAINER, EX. VALVE SPRING	1	
013	14775-ZE2-010	SEAT, VALVE SPRING	2	

<u>Ref</u>	<u>Partnumber</u>	<u>Description</u>	<u>GXV390UT1</u>	<u>Serial Numbers</u>
014	14781-ZE2-000	ROTATOR, VALVE	1	
015	14791-ZE9-010	GUIDE, PUSH ROD	1	
016	90012-ZE0-010	BOLT, PIVOT, 8MM	2	
017	90206-ZE1-000	NUT, PIVOT ADJUSTING	2	